

# Gigaset

## DL500 A

### Congratulations

By purchasing a Gigaset, you have chosen a brand that is fully committed to sustainability. This product's packaging is eco-friendly!

To learn more, visit [www.gigaset.com](http://www.gigaset.com).



GIGASET. INSPIRING CONVERSATION.  
**MADE IN GERMANY**



# Web configurator – Setting the phone using a PC

---

The Web configurator is the Web interface for your phone. It allows you to select the settings for your Gigaset DL500A via your PC's Web browser. You can use your phone's Web configurator to do the following:

- ▶ Configure access from your phone to the local network (IP address, gateway to the Internet).
- ▶ Load new firmware onto your phone if necessary.
- ▶ Use Internet services: Enable access to an online directory and display text information on the base (info services).
- ▶ Synchronise the date/time on the telephone with a time server on the Internet.
- ▶ Copy the contacts from the Outlook directory on your PC to the local directory on your base.  
Or:  
Back up your phone directories on a PC. Copy the entries to your Outlook directory.
- ▶ Obtain information about the status of your phone (firmware version, MAC address, phone numbers, connected handsets etc.).
- ▶ Back up your phone configuration on the PC and reload the back-up to the base when required.

# Contents

---

<b>Web configurator – Setting the phone using a PC</b> .....	1
<b>Web configurator menu</b> .....	4
<b>Connecting the PC with the telephone's Web configurator</b> .....	5
Establishing a connection via the base's IP address .....	5
Establishing a connection via Gigaset config .....	6
<b>Logging in to/off the Web configurator</b> .....	7
Logging in, setting the interface language .....	7
Logging off .....	8
<b>Understanding the structure of the Web configurator pages</b> .....	9
Menu bar .....	9
Using the navigation area .....	10
Using the working area .....	10
Using the buttons .....	11
Opening Web pages .....	12
<b>IP Configuration – Connecting to the LAN</b> .....	13
Assigning the IP address .....	13
Allowing access from other networks .....	14
Entering an HTTP proxy server (only when connected to an internal company network) .....	15
<b>Telephony – Connections:</b>	
<b>Change name, recall of fixed line network connection</b> .....	16
<b>Telephony – Connections:</b>	
<b>Information about GSM connections</b> .....	17
<b>Telephony – Number Assignment:</b>	
<b>Assigning send and receive connections</b> .....	18
Assigning receive/send connections to bases and handsets, changing internal names .....	19
Assigning receive connections to the answering machine .....	20
<b>Telephony – Dialling Plans:</b>	
<b>Entering your own area code/access code</b> .....	21
<b>Telephony – Network Mailboxes:</b>	
<b>Entering the network mailbox</b> .....	22
<b>E-Mail:</b>	
<b>Making e-mail settings</b> .....	23
<b>Services – Info Services:</b>	
<b>Configuring/activating the display</b> .....	24

<b>Services – Online Directory:</b>	
<b>Selecting an online directory</b> .....	<b>25</b>
<b>Phonebook Transfer:</b>	
<b>Deleting directories and loading to/from the PC.</b> .....	<b>26</b>
Loading the directory file from the PC to the base/handset .....	27
Loading the directory from the base/handset to the PC .....	27
Deleting the directory .....	27
Understanding directory file content (vcf file) .....	28
<b>Management – Date &amp; Time:</b>	
<b>Copying the date/time from the time server</b> .....	<b>29</b>
<b>Management – Miscellaneous:</b>	
<b>Reducing radiation – activating/deactivating Eco Mode</b> .....	<b>31</b>
<b>Management – Save &amp; Restore:</b>	
<b>Saving and restoring system settings</b> .....	<b>32</b>
Saving the settings for the base on your PC .....	32
Loading the settings from a file on the PC to the base .....	32
<b>Management – Firmware Update:</b>	
<b>Updating the base's firmware</b> .....	<b>33</b>
Starting the firmware update manually .....	33
Activating/deactivating the automatic version check .....	34
<b>Querying the phone status</b> .....	<b>35</b>
IP Configuration area .....	35
Software area .....	35
Fixed Line area .....	35
GSM Connections area .....	36
Registered Handsets area .....	36
Date and Time area .....	36
<b>Index</b> .....	<b>37</b>

# Web configurator menu

---

<b>Home</b>			
<b>Settings</b>	IP Configuration		→ <a href="#">page 13</a>
	Telephony	Connections	→ <a href="#">page 16</a>
		Number Assignment	→ <a href="#">page 18</a>
		Dialling Plans	→ <a href="#">page 21</a>
		Network Mailboxes	→ <a href="#">page 22</a>
	E-Mail		→ <a href="#">page 23</a>
	Services	Info Services	→ <a href="#">page 24</a>
		Online Directory	→ <a href="#">page 25</a>
	Phonebook Transfer		→ <a href="#">page 26</a>
	Management	Date & Time	→ <a href="#">page 29</a>
Miscellaneous		→ <a href="#">page 31</a>	
Save & Restore		→ <a href="#">page 32</a>	
Firmware Update		→ <a href="#">page 33</a>	
<b>Status</b>	Device		→ <a href="#">page 35</a>

# Connecting the PC with the telephone's Web configurator

---

## Prerequisites:

- ◆ A standard Web browser is installed on the PC e.g., Internet Explorer version 6.0 or higher, or Firefox version 1.0.4 or higher.
- ◆ The phone and PC are directly connected with each other via a router. The settings of any existing firewall installed on your PC allow the PC and phone to communicate with each other.

There are two ways of connecting your PC to the Web configurator of the base:

- ◆ Via the phone's IP address in the local network;
- ◆ Via the Gigaset configuration service, if the phone and PC are connected to the Internet (→ [page 6](#)).

### Please note

- ◆ The phone is **not** blocked while you select your settings in the Web configurator. You can make calls with your phone or modify settings at the same time.
- ◆ While you are connected to the Web configurator, it is blocked to other users. It cannot be accessed by more than one user at any time.

## Establishing a connection via the base's IP address

- ▶ Establish the current IP address of the base or handset. It is displayed when you open the following menu:

 →  **Settings** → **System** → **Local Network** (enter PIN if necessary)

Your phone's IP address can change if you have activated dynamic IP address assignment (→ [page 13](#)).

### Warning

If one of the four parts of the IP address contains leading zeros (e.g., 002), these zeros must not be entered in the Web browser address field. Otherwise, the Web browser will not be able to establish a connection to the Web configurator.

**Example:** The IP address 192.168.002.002 is displayed on the base. 192.168.2.2 should be entered in the address field.

- ▶ Launch the Web browser on your PC.
- ▶ Enter **http://** and the telephone's current IP address (for example: `http://192.168.2.2`) into the address field of the Web browser.
- ▶ Press the return key.

A connection is established to the phone's Web configurator.

## Establishing a connection via Gigaset config

**Prerequisite:** Your PC and base are connected to the Internet.

- ▶ Launch the Web browser on your PC.
- ▶ Enter one of the following URLs into the Web browser's address field:  
<http://www.gigaset-config.com>  
<http://www.gigaset-device.com>
- ▶ Press the return key.

You will receive a message stating that the connection has been forwarded to your base.

If several Gigaset phones can be reached via your Internet connection, you are asked which of these phones you would like to be connected to.

After successfully forwarding the connection, the Web configurator's **Login** page is displayed in the Web browser.

### **Please note**

The connection between the PC and the Web configurator is a local connection (LAN connection). The Internet is only accessed to establish the connection.



# Logging in to/off the Web configurator

## Logging in, setting the interface language

Once you have successfully established the connection, the **Login** Web page is displayed in the Web browser.




Figure 1 Start screen

You can select the language you want the menus and Web configurator dialogues to be displayed in. The language that is currently selected is displayed in the first field on the Web page.

- ▶ If necessary, click  to open the list of available languages.
- ▶ Select the language.

The Web page is reloaded in the selected language.

- ▶ Enter your base's system PIN (default setting: 0000) in the bottom field on the Web page to access the Web configurator functions.
- ▶ Click **OK**.

Once you have successfully logged in, the **Home** Web page opens with general information on the Web configurator.

If you enter an incorrect system PIN, a corresponding message is displayed. You are prompted to re-enter the PIN.

If you enter an incorrect system PIN a second time, the PIN field is blocked for a short time (greyed out). The duration of the block will double each time a PIN is subsequently entered incorrectly.

### Please note

- ◆ If the system PIN is still set as 0000 on the base (default setting), you will be notified during login that the unit is not secure and you should change the PIN. You can deactivate this security notice for subsequent logins by selecting the option "**Don't show this security notice again.**". Click on **OK** to close the dialog box.
- ◆ If you do not make any entries for a lengthy period (approx. 10 minutes), you are automatically logged off. The next time you try to make an entry or open a Web page, the **Login** Web page is displayed. Re-enter the system PIN to log back in again.
- ◆ Any entries that you did not save on the phone before automatic log-off will be lost.

## Logging off

In the menu bar (→ **page 9**) at the top right of every Web page in the Web configurator, you will see the **Log Off** command. Click **Log Off** to log off from the Web configurator.

### Warning

Always use the **Log Off** command to end the connection to the Web configurator. If, for example, you close the Web browser without logging off beforehand, it is possible that access to the Web configurator is blocked for a few minutes.

# Understanding the structure of the Web configurator pages

The Web configurator pages (Web pages) contain the UI elements shown in **Figure 2** (example).




Figure 2 Example of the structure of a Web configurator page

## Menu bar

The Web configurator menus are displayed in the form of tab pages in the menu bar.

The following menus are available:

### Home

The home page opens once you have logged in to the Web configurator. It contains information on the Web configurator functions.

### Settings

This menu allows you to make settings on your phone.

If you select the **Settings** menu, a list containing this menu's functions is displayed in the navigation area (→ **page 10**).

### Status

This menu provides you with information about your phone.

## Log Off

You will find the **Log Off** function to the right of the menu bar on every Web page.

### Please note

For an overview of the Web configurator menu, see → [page 4](#).


## Using the navigation area

The functions of the menu selected in the menu bar are listed in the navigation area (→ [page 9](#)).

If you select a function, the associated page containing information and input fields opens in the working area. The selected function is highlighted in orange.

If a function is assigned subfunctions, these are listed below the function as soon as you select the function (for example **Telephony**).

The relevant page for the first subfunction (highlighted in orange) is displayed in the working area.



## Using the working area

Depending on the function selected in the navigation area, information or dialogue boxes are displayed in the working area which allow you to make or change your phone settings.

### Making changes

Make settings via input fields, lists or options.

- ◆ There may be restrictions regarding the possible values for a field e.g., the maximum number of characters, entering special characters or certain value ranges.
- ◆ To open a list, click . You can choose between default values.
- ◆ There are two kinds of options:
  - Checkboxes: You can select one or more options from a list. Active options are indicated by , non-active options by . You can activate an option by clicking . The status of the other options in the list does not change. You can deactivate an option by clicking .
  - Alternative options (radio buttons). The active option in the list is indicated by , and the non-active by . You can activate an option by clicking . The previously activated option is deactivated. You can only deactivate an option by activating another option.

## Entering Cyrillic and Turkish characters

In the following section, the specified maximum number of characters permitted in a field refers to Latin characters and digits (1 character = 1 byte), i.e., 1 character means 1 byte.

Cyrillic and Turkish characters require 2 bytes each, e.g., with a field length of 16 characters, you can enter a maximum of 8 Cyrillic or Turkish characters.

If you enter too many characters into a field, the entry is rejected (not saved in the base). The "old" field content (or the default settings) are retained and displayed again when the Web page is updated. No warning/confirmation is given.

## Applying changes

As soon as you have made your change on a page, activate the new setting on the phone by selecting **Set**.

If your entry does not comply with the rules for this field, an appropriate error message is displayed. You can then repeat the input.

### Warning

Changes that have not been saved on your phone are lost if you move to another Web page or the connection to the Web configurator is lost e.g., due to exceeding the time limit ( → [page 8](#)).

## Using the buttons

Buttons are displayed in the bottom section of the working area. The following buttons are displayed depending on the function selected:

### Browse

Select a file on the PC whose Web browser is linked to the Web configurator.

### Update Firmware

Start a firmware update.

### Delete

Delete a file/directory.

### OK

Perform an operation (e.g., log in to the Web configurator, ).

### Cancel

Reject changes made on the Web page and reload the settings that are currently saved in your phone to the Web page.

### Restore

Load phone data (device settings) stored on the PC back on to the phone.

### Set

Store changes made on a Web page on the phone.

### Save

Save data that determines the settings/configuration of the base or a phone entry in a file on the PC.

### Transfer

Transfer the base's directory to the PC and store it there.

# Opening Web pages

A brief outline of how to navigate to the individual Web configurator functions is given below.

## Example

**Defining dialling plans:**

**Settings → Telephony → Dialling Plans**

To open the Web page, proceed as follows after registration:

- ▶ Select the **Settings** menu in the menu bar.
- ▶ Click the **Telephony** function in the navigation area.  
The **Telephony** subfunctions are displayed in the navigation tree.
- ▶ Select the **Dialling Plans** subfunction.

# IP Configuration – Connecting to the LAN

---

## Assigning the IP address

Select the necessary settings for operating your phone in your local network and for connecting it to the Internet, if necessary. For more detailed explanations of the individual components/terms, see the glossary in the user guide for the phone.

▶ Open the **Settings** → **IP Configuration** Web page.

### Address Assignment area

Specify the base's address in the LAN.

#### IP address type

Select **Obtained automatically**, if you want your phone to be assigned a dynamic IP address by a DHCP server in your local network. No further settings are needed. The following fields in this section are greyed out and deactivated.

Select **Static** if you would like to set up a static local IP address for your phone. A static IP address is useful, for example, if port forwarding or a DMZ is set up on the router for the phone. The phone often requires a static IP address, e.g., if you connect the phone directly to the PC.

The following fields are only activated if you select **IP address type** = **Static**:

#### IP address

Enter an IP address for your phone. This IP address allows your phone to be reached by other parties in your local network (e.g., PC).

192.168.2.2 is the default.

Please note:

- The IP address must be from the address block reserved for private use on the router. This is generally in the range 192.168.0.1 – 192.168.255.254 with **Subnet mask** 255.255.255.0. The subnet mask determines that the first three parts of the IP address must be identical for all subscribers in your LAN.
- The static IP address must not belong to the address block (IP pool range) that is reserved for the router's DHCP server. It must also not be used by another device on the router.

If necessary, check the settings on the router.

#### Subnet mask

Enter the subnet mask for your device's IP address. For addresses from the address block 192.168.0.1 – 192.168.255.254, the subnet mask 255.255.255.0 is generally used. This is preconfigured when the phone is supplied.

#### Default Gateway

Enter the IP address for the standard gateway through which the local network is connected to the Internet. This is generally the local (private) IP address for your router (e.g., 192.168.2.1). Your phone requires this information to be able to access the Internet.

192.168.2.1 is the default.

### Preferred DNS server

Enter the IP address for the preferred DNS server. DNS (Domain Name System) allows you to assign public IP addresses to symbolic names. The DNS server is required to convert the DNS name into the IP address when a connection is being established to a server.

You can specify your router's IP address here. The router forwards phone address requests to its DNS server.

192.168.2.1 is the default.

### Alternate DNS server (optional)

Enter the IP address for the alternate DNS server that should be used in situations where the preferred DNS server cannot be reached.

- ▶ Select **Set** to save the changes.

Or

- ▶ Select **Cancel** to reject the changes.

After you have changed the IP configuration, the base is rebooted. You are logged off the Web configurator. The **Login** Web page is displayed after the reboot.

## Allowing access from other networks

The default setting for your phone only allows you to access your phone's Web configurator via a PC that is in the same local network as your phone. The subnet mask of the PC must match that of the phone.

You can also allow access from PCs in other networks.

### Warning

Authorising access from other networks increases the risk of unauthorised access. It is therefore recommended that you deactivate remote access if you no longer require it.

- ▶ Open the **Settings** → **IP Configuration** Web page.

### Remote Management area

- ▶ Select **Yes** to authorise access from other networks.

To deactivate remote access, select **No**. Access is then limited to PCs in your own local network.

Access to the Web configurator services from other networks is only possible if your router is set accordingly. The router must pass on the service requests from "outside" to Port 80 (default port) of the phone. Be sure to read the user guide for your router.

To establish a connection, the public IP address or the DNS name of the router and, where applicable, the port number on the router must be indicated in the Web browser of the remote PC.



## Entering an HTTP proxy server (only when connected to an internal company network)

Direct connections between network subscribers and the Internet are often not permitted within internal company or organisation networks (Intranet). In such cases, all HTTP calls from the network are "transferred" by a proxy server. The proxy server is a computer or program within the network.

If your phone is connected to such a network, you must store the address of this HTTP proxy server on the phone and activate handling of HTTP calls via the HTTP proxy server.

Only then will you be able to access the online directory or display weather information etc. (information services).

- ▶ Open the **Settings** → **IP Configuration** Web page.

### HTTP proxy area

#### Enable proxy

Select **Yes** if your phone is to handle HTTP calls via your network's HTTP proxy server.

If you select **No**, the phone will attempt to access the Internet directly.

#### Proxy server address

Enter the URL of the proxy server to which your phone is to send HTTP calls. The proxy server then creates the connection to the Internet.

#### Proxy server port

Enter the communication port used on the HTTP proxy server (number between 0 and 55,000). It is mainly port 80 that is used.

- ▶ Select **Set** to save your settings.

# Telephony – Connections:

## Change name, recall of fixed line network connection

---

Your phone comes preset with a recall for general operation of the phone on the main connection. The recall specifies the duration of the line interruption used to send control signals to the exchange or the telecommunications system (transfer (ECT), setting up a consultation call, etc.). For operation on a PABX, you may have to change this value (please refer to the user guide for your PABX).

To change the setting:

- ▶ Open the **Settings** → **Telephony** → **Connections** Web page.

### Connection Name or Number

You can define a name for your telephone connection, which replaces the default name **Fixed Line** in displays or lists. Enter a name of up to 16 characters or the phone number of your fixed line network connection.

### Recall

- Select the required recall from the list.
- ▶ Select **Set** to save your settings.

# Telephony – Connections:

## Information about GSM connections

---

You can make calls on your base and/or a registered handset via the GSM connection of your Bluetooth GSM mobile phone (call external parties via the GSM connection of the mobile phone or receive calls to the GSM connection).

To do this, you can register up to five mobile telephones (i.e., save in the **Known Devices** list), which you can connect in alternation with your base.

For information about the registered GSM mobile phones:

▶ Open the **Settings** → **Telephony** → **Connections** Web page.

The GSM mobile phones are listed under the **GSM Connections** option. Five spaces are displayed, one for each possible GSM mobile telephone.

GSM Connections		
1.	MobTel 1	Registered
2.	MobTel 2	Connected
3.	GSM3	Not registered
4.	GSM4	Not registered
5.	GSM5	Not registered

The **GSM Connections** list is only for information. The **Known Devices** list and the properties of the GSM mobile phones can only be edited on the base. Further information can be found in the long user guide for the phone on the CD.

The following information is displayed:

### Name

The Bluetooth name under which the mobile phone is listed in the "Known Devices" list on the base is listed.

If a space in the list is not populated by a GSM mobile telephone, i.e., it is still free or occupied by a data device, **GSM** is displayed instead of a name.

## Status

### Registered

The mobile telephone is registered on the base, i.e., it is displayed in the **Known Devices** list. However, the mobile phone is not yet activated. The **Connect Mobile** option is **not** set for this mobile phone. No calls can be made from the base via the corresponding GSM connection.

### Connected

The mobile phone is displayed in the **Known Devices** list and is active. The **Connect Mobile** option is set for this mobile phone.

### Not registered

The position in the **Known Devices** list is still free or is not occupied by a GSM mobile phone (but instead by a Bluetooth data device).

## Telephony – Number Assignment: Assigning send and receive connections

---

This chapter is only relevant if at least one GSM mobile phone is registered via Bluetooth on the base.

You can specify which connections (fixed line network or Bluetooth mobile phone) should be assigned as receive and/or send connections for the base, each registered handset, and the local answering machine.

If a connection is the receive connection of the base, this rings when a call is received on this connection.

The send connection is the connection on which outbound calls are made.

### Please note

If you do not assign any numbers, the fixed line network connection and the GSM connection of the currently activated (connected) mobile phone (**GSM**) are assigned as receive connections to the base, the handsets, and the answering machine. The base and handsets use the fixed line network connection as a send connection.

For information about the Bluetooth interface of the phone, and connecting GSM mobile phones with the base, see the detailed user manual for the base on the enclosed CD.

# Assigning receive/send connections to bases and handsets, changing internal names

▶ Open the **Settings** → **Telephony** → **Number Assignment** Web page.

The following is displayed for the **Desktop Phone** and every handset (example):

The screenshot shows a web interface for configuring telephony settings. It is divided into two main sections: 'Desktop Phone' and 'Handsets'. Each section contains a form for a specific device (INT 1 and INT 2).

Desktop Phone	
INT 1	Name <input type="text" value="INT 1"/>
Connection	for outgoing calls      for incoming calls
Fixed Line	<input type="radio"/> <input checked="" type="checkbox"/>
MobTel 2	<input type="radio"/> <input checked="" type="checkbox"/>
Select line for each outgoing call	<input type="radio"/>

Handsets	
INT 2	Name <input type="text" value="INT 2"/>
Fixed Line	<input type="radio"/> <input checked="" type="checkbox"/>
MobTel 2	<input type="radio"/> <input checked="" type="checkbox"/>

The default name (**INT 1** to **INT 7**), any name you have set, and a list of available connections are displayed for each handset and the base. Under **Connection**, **GSM** is displayed for the GSM connection, and for the fixed line network connection, the name you specified (→ [page 16](#)) or the default name **Fixed Line**. The GSM connection is only displayed if the list of known devices contains at least one GSM mobile phone.

- ▶ If necessary, change the internal name of the device (base/handset) in the **Name** field.
- ▶ Define a connection as the send connection for each device. To do this, select the option (radio button) following the connection in the **for outgoing calls** column. The previous assignment will automatically be deactivated.  
If you select the option **Select line for each outgoing call** instead, you can select which connection is used every time you make a call.
- ▶ For each device, select the connections that are to be assigned to the handset as receive connections. To do so, click the option following the connection in the **for incoming calls** column. You can assign one, both, or no connection for each device ( = assigned).
- ▶ Select **Set** to save your settings.

### Please note

- ◆ If all mobile phones are deleted from the list of known devices (de-registered), the fixed line network connection is automatically assigned as the send connection for any device to which the GSM connection was assigned as the send connection.
- ◆ If a connection is not assigned to a device as a receive connection, calls to this phone number are signalled neither on the base nor any handset.

## Assigning receive connections to the answering machine

You can choose whether the answering machine should receive calls for the connections of the base. For the GSM connection, the name of the corresponding Bluetooth mobile telephone is displayed in the list of known devices.

- ▶ Open the **Settings** → **Telephony** → **Number Assignment** Web page.

Answering machine	
Select the answering machine to store incoming calls for each connection.	
Fixed Line	AM 1
MobTel 2	None

- ▶ In the **Answering Machine** area, select **AM 1** for both the fixed line network and the GSM connection if you want the answering machine to receive calls for this connection (must be activated).  
Select **None** if you do not want the answering machine to receive calls on this connection.
- ▶ Select **Set** to save your settings.

# Telephony – Dialling Plans:

## Entering your own area code/access code

---

On the base, save the complete code (with international code) for the area in which you are using the phone.

If your base is connected to a PABX, you may have to enter an access code for external calls (external prefixes e.g., "0"). You can save this access code on the base.

- ▶ Open the **Settings** → **Telephony** → **Dialling Plans** Web page.

### Area Codes area

Configure the following settings here:

- ▶ From the **Country** list, select the country in which you are using your phone. This way, the international prefix (**International Prefix** and **Area Code**) and the prefix of the area code (**Local Prefix Area Code**) are set automatically.
- ▶ In the **Local Area Code** field, enter the area code for your town without a prefix (maximum 8 figures 0–9, \*, #, R, P e.g., 131 (for Edinburgh)).

### Access Code area

- ▶ Enter the access codes in the **Code for Fixed Line** field that should prefix phone numbers (max. 3 digits).
- ▶ Select a figure from the **is added to numbers** list when the phone numbers should be prefixed by the access code.

#### from Call Lists

The access code prefixes numbers dialled on the base or handset selected from a call list, the SMS list or an answering machine list.

#### All

The access code prefixes all numbers dialled on the base or a handset.

#### None

The access code does not prefix any phone number before being dialled.

- ▶ Select **Set** to save the settings.

# Telephony – Network Mailboxes:

## Entering the network mailbox

---

Many fixed line network providers offer answering machines on the network – these are known as network mailboxes.

By saving the network mailbox number on the base, you can assign it to key 1 for fast access or call it directly by opening the message list.

- ▶ Open the **Settings** → **Telephony** → **Network Mailboxes** Web page.
- ▶ Enter the number of the network mailbox in the **Network Mailbox Number** field.
- ▶ Select **Set** to save your settings.

### **Please note**

The network mailbox must have been **requested** from the network provider.  
For instructions on activating/deactivating the network mailbox, see the information provided by your network provider.



# E-Mail:

## Making e-mail settings

---

You can use your phone to be notified about new e-mail messages on your incoming e-mail server and to display the incoming e-mail list and the text of the messages on the handset.

You must store the address or DNS name of your incoming e-mail server and your personal access data in the phone and activate the e-mail check with the incoming e-mail server, so that the phone can establish a connection to the incoming e-mail server and connect to your mailbox.

- ▶ Open the **Settings** → **E-Mail** Web page.
- ▶ Enter the user name (account name) agreed with the Internet provider (max. 74 characters) in the **Authentication Name** field.
- ▶ Enter the password agreed with the provider for accessing the incoming e-mail server (max. 32 characters; case sensitive) in the **Authentication password** field.
- ▶ Enter the name of the incoming e-mail server (POP3 server) (max. 74 characters) in the **POP3 Server** field. Example: pop.theserver.com.
- ▶ From the **Check for new e-mail** list select the time interval at which your phone should check if new messages have arrived in your incoming e-mail server. Select **Never** to deactivate the prompt. Select one of the other values to activate the prompt for new e-mail messages.
- ▶ Select the **Set** button to save the settings in your phone.

# Services – Info Services:

## Configuring/activating the display

---

You can configure your base to display customised text information (e.g., weather reports, news feeds, eBay messages, traffic reports) in the idle display. To do so, you must set the **Info Services** screensaver on the base.

### Configuring info services

#### Please note

The default setting is the weather report. It is shown in the base's idle display as soon as you set **Info Services** as a screensaver.

▶ Open the **Settings** → **Services** Web page.

▶ Click the link

[www.gigaset.net/myaccount](http://www.gigaset.net/myaccount)

The Web page for Gigaset.net info services is opened. You are already registered with your Gigaset.net user ID. Your Gigaset.net user ID and your password are displayed on the **Services** page of the Web configurator.

This opens a Web page where you can compile your info service.

▶ Define which information should be sent regularly to your base and connected handsets.

### Activating info service display

In the **Activate Info Services** area:

▶ Activate **Yes / No** to switch the display of text information on or off.

▶ Select the **Set** button to save the settings in your phone.

If text information is available and **Info Services** is set as the screensaver, the information appears in the idle display of the base and all registered Gigaset SL78H, SL400H or S79H handsets.

If no text information is available, the digital clock will appear in the idle display instead.

# Services – Online Directory:

## Selecting an online directory

---

You can use online phone directories (public directory, classified directory and/or your private net directory) on the base and registered handsets. You can use your telephone's Web configurator to define which online directory you wish to use.

You can also elect to display the name under which the caller making an incoming call is saved in the online directory (**Display of caller's name**) – in the call display on the base and in the call list.

**Prerequisite:** This function is supported by the provider of the online directory.

- ▶ Open the Web page **Settings** → **Services** → **Online Directory**.
- ▶ Select the provider whose online directory you wish to use from the **Provider** list. Select **none** if you do not wish to use an online directory.

The following fields are displayed depending on the **Provider** you select:

### Display of caller's name

This is displayed if the provider supports copying of the caller name from the online directory to the call display.


- ▶ Select **On** to update the display.

### Entering Authentication password and Authentication Name

These fields are displayed if you need to register with the provider to gain access to certain services:

- ◆ Some providers require you to register every time you want to access their online directory. They require registration with authentication name and password for access to the online directory. You must store this data on the base.
- ◆ Other providers differentiate between standard and premium services. You can access standard services **without** entering an authentication name and password. But you will have to register to use the premium services. You will need to save the access data in your base to gain access to premium services.
- ▶ Enter the data received from the provider in the **Authentication Name** (max. 74 characters) and **Authentication password** (max. 20 characters) fields.
- ▶ Click the **Set** button to save the settings in your phone.

#### Please note

- ◆ Instructions on using online directories on the base are included in the detailed user guide for the phone.
- ◆ In the list of online directories (press  **and hold**), the provider-specific names of the online directories are displayed.
- ◆ If you select **none** from the **Provider** list, the entries for online and classified directories are not displayed in the list of online directories on the base or handsets.

# Phonebook Transfer:

## Deleting directories and loading to/from the PC.

---

The Web configurator provides the following options for editing the directories of the base and registered handsets.

- ◆ Store the directories on a PC. Entries are stored in vCard format in a vcf file on the PC. You can edit these files with an ASCII editor (e.g., Notepad/Editor in Windows Accessories) and load them onto the base or any registered handset. You can also copy directory entries to your PC directory.
- ◆ Copy contact details from your PC directory to directories on the base and handsets. Export the contacts in vcf files (vCards) and transfer them to directories for the base and handsets using the Web configurator.
- ◆ Delete the directory on the base/handset.

If you have edited the directory file (vcf file) on the PC and would like to load this modified directory to the base/handset, you can delete the current directory on the base/handset before the transfer.

**Tip:** Back up the current directory on your PC before deleting it. You can then reload it if the modified directory is affected by formatting errors and some, or all, of it cannot be loaded onto the base/handset.

### Please note

- ◆ You can find information on vCard format (vcf) on the Internet e.g., at: [www.en.wikipedia.org/wiki/VCard](http://www.en.wikipedia.org/wiki/VCard) (English) or [www.de.wikipedia.org/wiki/VCard](http://www.de.wikipedia.org/wiki/VCard) (German)  
(You can set the display language at the bottom left-hand side in the navigation area of the Web page.)
- ◆ If you wish to copy a directory (vcf file) with multiple entries stored on the PC to the Microsoft Outlook™ directory, please proceed as follows:  
Microsoft Outlook™ only ever transfers the first (directory) entry from the vcf file to its directory.  
You can use the **Gigaset QuickSync** program (included with the phone) to compare the directory on the base with the Outlook directory. You will find it on the enclosed CD.

### Prerequisites:

- ◆ The base can send and receive directory entries.
- ◆ The handset is activated and is in idle status.
- ▶ Open the **Settings** → **Phonebook Transfer** Web page.

In the **Export and import phone books** area, the base (**Desktop Phone**) and the names of all registered handsets are shown (**Handset** section).

- ▶ Select the base or handset for which you want to save or edit the directory. To do this, click the option in front of the base/handset.

## Loading the directory file from the PC to the base/handset

- ▶ In the "**Transfer directory from PC to handset.**" area, enter the vcf file you want to load onto the device (complete path name), or click **Browse...** and navigate your way to the file.
- ▶ Select **Transfer** button to start the transfer.

The display will show how many of the entries from the vcf file are being transferred to the directory.

### Transfer rules

The directory entries from a vcf file that are loaded onto the base/handset are added to the directory. If an entry already exists for a name, it will either be supplemented or a new entry for the name is created. The process will not overwrite or delete any phone numbers.

#### Please note

Depending on your device type, up to 3 entries with the same name are created in the directory for each vCard – one entry per entered number.

## Loading the directory from the base/handset to the PC

- ▶ Select **Save** in the **Save directory to PC** area. A browser dialogue box appears where you can open/save the file.

## Deleting the directory

- ▶ Select **Delete** in the **Delete directory** area.
- ▶ Confirm the **Telephone directory of the selected handset will be deleted. Continue?** security prompt with **OK**.

All directory entries are deleted.

## Understanding directory file content (vcf file)

The following data (if available) is written into the vcf file for entry into the directory or transferred from a vcf file into the handset directory.

- ◆ Name
- ◆ First name
- ◆ Number
- ◆ Number (office)
- ◆ Number (mobile)
- ◆ E-mail address
- ◆ Birthday (YYYY-MM-DD) and time of the reminder call (HH:MM) separated by a "T" (example: 2008-12-24T11:00).

Other information that a vCard may contain is not entered into the base/handset directory.

### Example of an entry in vCard format:

```
BEGIN:VCARD
VERSION:2.1
N:Smith;Anna
TEL;HOME:1234567890
TEL;WORK:0299123456
TEL;CELL:0175987654321
E-MAIL:anna@smith.com
BDAY:2008-12-24T11:00
END:VCARD
```

# Management – Date & Time:

## Copying the date/time from the time server

---

The date and time are shown in the idle display of the base and registered handsets. They are important, for example, for stating the correct time in the answering machine list, call lists and for the "anniversary", "appointments" and "alarm clock" functions.

There are various ways to update the date and time:

- ◆ Manually on the base or on one of the registered handsets
- ◆ Automatically through synchronisation with a time server on the Internet

Activate/deactivate synchronisation with a time server as follows:

- ▶ Open the **Settings** → **Management** → **Date & Time** Web page.
- ▶ In the **Automatic adjustment of System Time with Time Server** field, select **Yes** to activate synchronisation between the base and a time server. If you select **No** the base will not adopt time settings from a time server. In this case, set the time and date manually using a handset.
- ▶ The **Last synchronisation with time server** field indicates the last time the base compared the time and date settings with a time server. The field is only shown if synchronisation is enabled.
- ▶ In the **Time Server** field, enter the Internet address or DNS name of the time server from which the base should adopt its time and date settings (maximum 74 characters). The time server "europe.pool.ntp.org" is set as default. You can overwrite the setting.
- ▶ From the **Country** list, select the country in which you are using your phone.
- ▶ The **Time Zone** field shows the valid time zone for the **Country**. It shows the deviation between local time (not summer time) and Greenwich Mean Time (GMT).  
If a country is divided into various time zones, they will all appear in the list. Select the appropriate **Time Zone** for the phone from the list.
- ▶ The **Automatically adjust clock to summer-time changes** field is displayed if your time zone differentiates between British summer time and standard time. Select **Yes** if you want the time to change automatically to summer time or standard time when British summer time begins and ends respectively. Select **No** if you do not want to change to summer time.  
**Please note:** If the date and time are updated by a time server that automatically switches between summer time and standard time, you must always select **No** here.
- ▶ Select the **Set** button to save the settings in your phone.

Once you have activated synchronisation, the time and date are compared with a time server as soon as an Internet connection is established.

Synchronisation will usually occur once a day (at night) if synchronisation is activated. Any additional synchronisation will take place only after each system start of the base (e.g., after a firmware update or a power cut).

If you register a new handset on your base, it will assume the time and date of the base without any additional synchronisation with the time server.

Date and time settings are transferred to every registered handset after synchronisation.

#### **Please note**

- ◆ The default time server "europe.pool.ntp.org" will remain stored on the base even if you overwrite it. If you delete your time server from the **Time Server** field and synchronisation is still activated, the base will continue to synchronise with the default time server. However, it will no longer appear in the **Time Server** field.
- ◆ If you have entered your own time server in the **Time Server** field, and the base is unable to synchronise for ten consecutive attempts, the base will synchronise with the default time server on the next synchronisation.



# Management – Miscellaneous:

## Reducing radiation – activating/deactivating Eco Mode

---

The radiation from the registered handsets reduces **automatically** depending on their distance to the base. The closer the handsets are to the base, the lower the radiation.

You have the following options:

### Eco Mode - Further reducing radiation

You can further reduce the radiation from the handsets and base by using **Eco Mode**.

**Eco Mode** reduces radiation by 80% – whether you are making a call or not. **Eco Mode** reduces the range of the base by approx. 50%. Using **Eco Mode** always makes sense when a reduced range is sufficient.

### Eco Mode+ - Deactivating radiation



When you activate **Eco Mode+**, the radiation (DECT transmission power) from the base and handset is deactivated in idle status, assuming all registered handsets support **Eco Mode+**.

**Eco Mode** / **Eco Mode+** can be activated/deactivated independently of one another and can also be used when multiple handsets are registered on the base.

### Activating/deactivating Eco Mode/Eco Mode+

- ▶ Open the **Settings** → **Management** → **Miscellaneous** Web page.
- ▶ Enable/disable **Eco Mode** to activate/deactivate Eco Mode.
- ▶ Enable/disable **Eco Mode+** to activate/deactivate Eco Mode+.
- ▶ Select **Set** to save the changes.

#### Please note

- ◆ If **Eco Mode+** is activated, the  icon appears in the idle display. If you have only activated **Eco Mode+**, the  icon is white; if **Eco Mode** is also activated, then the icon is green.
- ◆ When using **Eco Mode+**, you can ensure that the base is in range by pressing and **holding** the talk key. You hear the dial tone if the base can be reached.
- ◆ When **Eco Mode+** is enabled:
  - Call setup is delayed by approx. 2 seconds on the handset.
  - Handset standby time is reduced in certain circumstances.
- ◆ Registering handsets that do not support **Eco Mode+** causes the mode to be deactivated on the base and all other registered handsets.
- ◆ Activating **Eco Mode** reduces the range of the base.
- ◆ If you use a repeater, you cannot use **Eco Mode** or **Eco Mode+**.

# Management – Save & Restore:

## Saving and restoring system settings

---

After configuring your base, you can save the current settings in a file on your PC. The file will then contain, for example:

- ◆ The settings for the local network (IP configuration), → [page 13](#)
- ◆ Your own local area code and access code, → [page 21](#)
- ◆ Network mailbox number, → [page 22](#)
- ◆ The info services settings, → [page 24](#)
- ◆ The settings for synchronisation with a time server, → [page 29](#)
- ◆ The ECO DECT settings, → [page 31](#)
- ◆ The settings for ringer melodies and volume levels

If you change the settings accidentally or you need to reset the base due to a fault, you can reload the saved settings from the file on your PC to your phone.

- ▶ Open the **Settings** → **Management** → **Save & Restore** Web page.

## Saving the settings for the base on your PC

In the **Save device settings to PC** area:

- ▶ Click the **Save** button next to **Save settings**.  
The base will create a file Gigaset-yyyy-mm-dd.cfg (default name; yyyy = year 4-digit format, mm = month 2-digit, dd = day 2-digit) with the configuration data.
- ▶ A browser-specific dialogue box appears where you can open/save the file. Change the name, if necessary, and save the file on your PC.

## Loading the settings from a file on the PC to the base

**Prerequisite:** There is a .cfg file with the settings for the base on your PC.

In the **Reload device settings from PC** area:

- ▶ In the **Settings File** field, enter the .cfg file you want to load onto the base (complete path name), or click **Browse...** and navigate your way to the file.
- ▶ Select **Restore** button to start the transfer.

# Management – Firmware Update:

## Updating the base's firmware

---

If necessary, you can load updates of the base firmware onto your base.

The server on which new firmware versions are generally available to download to your base is set by default. The URL of the Internet server is displayed in the **Data server** field.

### Please note

- ◆ You should only change this URL under exceptional circumstances (e.g., if requested to do so due to a malfunction). You should make a note of the default URL before you overwrite it. Otherwise, you will only be able to reactivate the default URL by resetting the base back to the default settings.
- ◆ When updating from the Internet, checks are made to ensure that no **new** version of the firmware exists. If this is not the case, the operation is terminated. You will receive a message to this effect.
- ◆ The firmware is only loaded from the Internet if you have not entered a local file in the **User defined firmware file** field prior to the update.

## Starting the firmware update manually

### Prerequisites:

- ◆ The base has a connection to the Internet.
- ◆ No calls are being made.
- ◆ There is no internal connection between the base and registered handsets.
- ◆ No handset has the base menu open.
- ▶ Open the **Settings** → **Management** → **Firmware Update** Web page.
- ▶ Select the **Update Firmware** button.

If a newer firmware version is available, this is loaded to the base. Your connection to the Web configurator is terminated, and the base is rebooted.

This process can take up to 3 minutes.

### Please note

In exceptional circumstances you may receive, for example, a firmware file from Service that you can upload from the local PC to your telephone (e.g., because the firmware update via the Internet did not work). Check the prerequisites for your PC.

- ▶ First download the firmware file to your PC, and in the **User defined firmware file** field, enter the IP address of the PC in your local network and the full path and name of the firmware file on the PC (max. 74 characters).
- ▶ Now click the **Set** button, and then the **Update Firmware** button to start the update.

The information in the **User defined firmware file** field is only used during **this** (following) firmware update.

If an error arises during a firmware update from a local PC, the new version of the firmware is automatically downloaded from the Internet.

## Resetting the firmware - reload the previously downloaded firmware version in the phone

You can reload the firmware version that was loaded before the last update on the phone. The new firmware is overwritten.

- ▶ Select the **Downgrade Firmware** button. The text above this button shows the version of the firmware that you want to reload
- ▶ In the following dialog box, click the **Yes** button to confirm the prompt.

The firmware loaded before the last update is reloaded to the phone. Your connection to the Web configurator is terminated, and the base is rebooted.

This process can take up to 3 minutes.

## Activating/deactivating the automatic version check

When the version check is activated, the phone checks on a daily basis whether the Gigaset configuration server has a new version of the phone firmware.

If a new version is available, a notification is sent to the base and the corresponding message flashes. You can then perform an automatic update of the firmware.

Please refer to the user guide for the base.

- ▶ Open the **Settings** → **Management** → **Firmware Update** Web page.
- ▶ Select **Yes** next to **Automatic check for software/profile updates** to activate the automatic version check.  
Select **No** if you do not want a version check to be carried out.
- ▶ Select **Set** to save the changes.

### Please note

If the telephone is not connected to the Internet at the time when the check for new versions is to be carried out (e.g., because the router is deactivated), the check is carried out as soon as the phone is reconnected to the Internet.

# Querying the phone status

---

General information about your phone is displayed.

▶ In the menu list, select the **Status** tab.

The following information is displayed:

## IP Configuration area

### IP address

The phone's current IP address within the local network. For details on assigning the IP address, → [page 13](#).

### MAC address

The phone's device address.

## Software area

### Firmware version

Version of the firmware currently loaded on the phone. You can download updates of the firmware to your phone. Firmware updates are available on the Internet.

The version number is displayed in the following format: Vxx.xx-yy.yy.yy.

xx.xx denotes the phone's product variant

yy.yy.yy denotes the version of firmware (the first two digits) and the sub-version.

The edition V41.00-30/01/00 means that firmware version 30 is currently loaded on your base.

## Fixed Line area

The name that you have defined for your fixed line network connection or the default name **Fixed Line** is displayed.

## GSM Connections area

The mobile telephones registered via the Bluetooth interface of the base are listed:

### **Name**

The Bluetooth name under which the mobile phone is entered in the list of "known devices" on the base.

### **Status**

#### **Registered**

The mobile phone is registered to the base, i.e. it appears in the **Known Devices** list. However, the mobile phone is not yet activated. The **Connect Mobile** option is **not** set for this mobile phone.

#### **Connected**

The mobile phone is displayed in the **Known Devices** list and is active. The **Connect Mobile** option is set for this mobile phone.

Further information about the Bluetooth interface of the base and the connected devices can be found in the long user guide for the phone on the CD.

## Registered Handsets area

All handsets registered on the base are listed. The internal names for the handsets are displayed. If you have not assigned a name to a handset, then the default name **INT 2, INT 3 ....** is shown.

## Date and Time area

### **Time**

Time currently set on the base.

### **Date**

Date currently set on the base.

### **Last Synchronisation**

If synchronisation to a time server is activated ( → [page 29](#)), the time when the last synchronisation procedure occurred is shown here.

# Index

---

## A

- Access code
  - entering..... 21
- Access to Web configurator services
  - from other networks ..... 14
- Account name (e-mail) ..... 23
- Adapter plug
  - power saving ..... 31
- Address assignment (IP address)..... 13
- Alternate DNS server ..... 14
- Answering machine
  - assigning receive connections ..... 20
- Area code
  - entering own ..... 21
- Automatic version check..... 34

## B

- Base
  - assigning receive connection ..... 19
  - assigning send connection..... 19
- Base firmware
  - updating ..... 33

## C

- Call display
  - name from online directory ..... 25
- Change recall ..... 16
- Changing to summer time ..... 29
- Checkboxes ..... 10
- Connecting
  - to internal company network ..... 15
- Connecting the PC to the Web configurator.....5
- Connection
  - Phone to LAN..... 13

## D

- Data server for firmware update ..... 33
- Date
  - transferring from time server..... 29
- DECT transmission power
  - reducing ..... 31
- Deregistering
  - from Web configurator .....8

## Device management

- date and time..... 29
- firmware update ..... 33
- miscellaneous ..... 31
- save & restore..... 32

## Directory

- deleting..... 27
- loading from PC ..... 27
- transferring to/from PC..... 26

## Directory file

- content (vCard format) ..... 28

## Directory transfer ..... 26

## Display

- name from online directory ..... 25

## DNS server

- alternate ..... 14
- preferred ..... 14

## Dynamic IP address ..... 13

## E

### Eco Mode

- activating/deactivating..... 31

### Eco mode ..... 31

### Eco Mode+

- activating/deactivating..... 31

### Eco mode+ ..... 31

## E-mail

- account name ..... 23
- entering access data ..... 23
- incoming e-mail server ..... 23
- registration name/password ..... 23
- settings ..... 23
- Entering access data (e-mail) ..... 23
- Entering Arabic characters ..... 11
- Entering Cyrillic characters ..... 11
- Entering Cyrillic/Arabic characters..... 11

## F

### Firmware

- automatic update ..... 34
- checking version..... 35
- starting update ..... 33

## G

- Gigaset config ..... 5, 6
- GSM connection ..... 17, 19
  - assign to answering machine ..... 20
- GSM mobile telephone ..... 17

## H

Handset	
assigning receive connection	18
assigning send connection	18
HTTP Proxy	15

## I

Incoming e-mail server (e-mail)	23
Info services	24
configuring	24
Input fields	10
Interface language	
Web configurator	7
Internal company network	15
Intranet	15
IP address	
assigning	13
automatically obtaining one	13
checking	35
IP address type	13
IP configuration	
Web configurator	13

## K

Known devices (Bluetooth)	17
---------------------------	----

## L

LAN	
connecting phone	13
Language	
Web configurator	7
List of known devices	17
Lists	10
Local Network	13

## M

MAC address	
checking	35
Menu	
Web configurator overview	4
Menu bar	9

## N

Name	
of caller from online directory	25
Network mailbox	
entering number	22
saving number	22
Number assignment	19, 20

## O

Online directory	
selecting	25
Opening	
Web page	12
Options	10
Own area code	
entering	21

## P

Phone	
connecting to internal company	
network	15
Phone status	35
POP3 server	23
Power saving adapter plug	31
Preferred DNS server	
entering	14

## R

Radiation	
deactivating	31
reducing	31
Radio buttons	10
Receive connection	
assigning to answering machine	20
assigning to base	19
assigning to handset	18
Reduced energy consumption	31
Registering	
with Web configurator	7
Registration name	
e-mail	23
Registration password	
e-mail	23
Remote access to Web configurator	14
Remote management	14

## S

Send connection	
assigning to base	19
assigning to handset	18
Server	
for firmware update	33
Services	
info services	24
online directory	25
Setting	
online directory	25



- Setting the time zone..... 29
- Standard gateway
  - entering..... 13
- Static IP address..... 13
- Status
  - of the phone..... 35
- Structure of Web page.....9
- Subnet mask
  - defining..... 13
- Summer time
  - changing automatically to ..... 29
- Synchronisation with time server ..... 29

**T**

- Telephony
  - network mailbox..... 22
  - number assignment..... 18
- Text information
  - in idle display..... 24
- Time
  - transferring from time server..... 29
- Time server ..... 29
- Transferring PC directory entries
  - to directory..... 26

**U**

- Using the buttons..... 11
- Using the navigation area..... 10
- Using the working area ..... 10

**V**

- vCard format..... 28
- vcf file..... 26
- Version check
  - automatic ..... 34

**W**

- Weather forecasts
  - in idle display mode..... 24
- Web configurator .....1
  - checking firmware version ..... 35
  - connecting with PC .....5
  - defining IP address..... 13
  - deregistering .....8
  - firmware update ..... 33
  - interface language.....7
  - IP configuration..... 13
  - local network..... 13
  - menu .....4
  - number assignment..... 19, 20
  - remote access ..... 14
  - selecting IP address type ..... 13
- Web interface, see Web configurator
- Web page
  - opening..... 12
  - structure .....9
- Web server, see Web configurator

**Issued by**

Gigaset Communications GmbH  
Frankenstr. 2a, D-46395 Bocholt

**© Gigaset Communications GmbH 2011**

All rights reserved. Subject to availability.

**Rights of modification reserved.**

[www.gigaset.com](http://www.gigaset.com)

This user guide is made from 100% recycled paper.