

## Downloading and deleting files

Using Gigaset QuickSync, you can download screensavers, caller ID images and ringtones from your Gigaset to the Mac. You can also delete these files from the Gigaset.

- Click on the "Photos" tab to open the file browser list



### Downloading a file

- Click on the appropriate file to select it
  - Drag the files from the program window to the Mac
- or
- Click "Download to Mac" and then select the file's target directory on the Mac.
  - Confirm with "Save"

### Deleting a file

- Click on the appropriate file to select it
- Click on "Delete"

### Attention

Once deleted, the file can no longer be restored and is removed from the Gigaset without a prompt.

The Gigaset must be in idle status when downloading and deleting files.