


How can you enter the prefix codes?


If your telephone is connected to a PABX, you may initially have to enter a prefix (access code) for external calls. Please refer to the operating instructions for your PABX. The prefix can consist of one to four digits.


In the case of incoming calls, the prefix is automatically added to the caller's number in the display, in the missed calls list and thus also in the telephone directory (if copied there from the missed calls list). The number stored can be dialled directly from the missed calls list.

Entering a prefix (access code)




1. Open the menu, press control key  (on the dark displayed side).



2. Select "Base Settings", press control key  and confirm with display key **OK**.



3. Select "Settings" with display key **↓** or **↑**. Confirm with display key **OK**.



4. Select "System settings" with display key **↓** or **↑**. Confirm with display key **OK**.



5. Select "Access code" with display key **↓** or **↑**. Confirm with display key **OK**.



6. Delete, change or insert and confirm with display key **≡+**.



7. "Save entry". Confirm with display key **OK**.
- When dialling manually or entering telephone directory, emergency or DSS numbers, the prefix must be specified explicitly.