













# Gigaset SX303 / SX353isdn




# Gigaset SX303 / SX353isdn

## + Gigaset S1 C1 C2 SL1



③ Mobilteil anmelden  
 Registering the handset  
 Déclarer le combiné  
 Handset aanmelden  
 Registrare il portatile  
 Registrar el terminal inalámbrico  
 Registrar terminal móvel  
 Rejestracja słuchawki  
 Přihlásit přenosný přístroj



# Gigaset SX303 / SX353isdn

## + Gigaset USB Adapter DECT

