# Configuring the first VoIP connection

Prerequisites:

➢ The phone and PC are connected to the router and the router is connected to the internet

➢ A Web browser is installed on the PC

➢ Any existing firewall allows the PC and the phone to communicate

➢ You have opened an account with a VoIP provider

Open Web-Configurator:

➢ Enter the following URLs into the Web browser's address field:
http://www.gigaset-config.com

Oder

➢ Enter the telephone's current **IP address** (for example:http://192.168.2.173) into the address field of the Web browser.

Configuring the first VoIP connection

Welcome

You can use this interface to administer your device. For your security, the configuration program is protected with the system PIN.

Please choose your language for menus and dialogs:

English ▾

Please enter your system PIN:

[   ] OK

Once you have successfully established the connection, the browser displays the **<Welcome>** Web configurator page.

➢ In the top field, select a different language if required.
➢ Enter your phone`s four-digit-system PIN in the bottom field. The default is '0000'.
➢ Click on **<OK>**
➢ If a security instruction is displayed: click on **<OK> again.**

Configuring the first VoIP connection

➢ Click on **<Settings>**

➢ Click on **<Telephony>** in the navigation tree(left) for the following Web page.

The **<Connections>** Web page opens with all your phone`s existing connections and all thosethat can still be configured.

➢ Click on the **<Edit>** button linked to IP connection **<IP1>**

Configuring the first VoIP connection

➤ Click on **<Start Configuration Assistant>**

Configuring the first VoIP connection

> Choose the option <**No**> and click <**Next>** to continue

Configuring the first VoIP connection

- ➢ From the list, select the **country** for which the list of VoIP providers is to be loaded

- ➢ Click on **<Next>**

Configuring the first VoIP connection

> Select your **VoIP provider** from the list

If your provider is not included in the list, select **<Other Provider>**. In this case you will have to enter the general provider data by hand.

> Click on **<Finish>**

Configuring the first VoIP connection


The details of the selected provider are loaded to your phone.

➢ To complete configuration of your VoIP connection, enter your **account data** in the **Personal Provider Data area.**

➢ Click on **<Next>**

Configuring the first VoIP connection

Registration was successful

➢ Click on **<OK>**

Configuring the first VoIP connection

> If your provider has set up a mailbox for you, please enter the phone number.

> Define whether all outgoing calls should be handled via this VoIP connection.

Configuring the first VoIP connection

➢ Click on **<Set>** to save the provider data and settings.