

Auto configuration with using an auto configuration code

The entire configuration process for a VoIP connection is automated for some VoIP providers. You can download the necessary VoIP access data to your phone from the Internet.

Prerequisites:

- You have received an **auto configuration code** from your VoIP provider.
- The general access data for your VoIP provider is available for downloading.

You can download all the data required for VoIP access from the Internet:

- Enter the auto configuration code you received from your VoIP provider in the Auto Configuration area in the **Auto Configuration Code** field (maximum 32 characters).
- Select the Start **Auto Configuration** button.

The screenshot displays a web interface for IP Configuration. The left sidebar contains a navigation menu with categories: IP Configuration, Telephony, Connections (highlighted), Audio, Number Assignment, Call Forwarding, Dialling Plans, Network Mailbox, Advanced Settings, Messaging, Services, Handsets, Security, and Miscellaneous. The main content area is titled '1. IP Connection' and includes a 'Log Off' link in the top right. The 'Auto Configuration' section contains a text input field for 'Auto Configuration Code' and a 'Start Auto Configuration' button, both of which are circled in red. Other fields include 'Connection Name or Number' (with 'IP1' entered), 'Provider' (with 'Other Provider' selected and a 'Select VoIP Provider' button), and 'Personal Provider Data' (with fields for Authentication Name, Authentication password, Username, and Display name). A 'Show Advanced Settings' button is located below the personal data fields. At the bottom, there are 'Set', 'Cancel', and 'Delete' buttons.

The telephone establishes a connection to the Internet and downloads all data required for the VoIP connection, i.e., the general provider information and your personal provider data (account data) are saved to your base.

If you have already entered details on the Web page, this is deleted as soon as Start Auto Configuration is selected. The fields in the Personal Provider Data and General data of your service provider areas and the server addresses in the Network data for your service provider area are overwritten by the downloaded data.

Generally, you should not have to enter any additional data on this Web page.

When the download is complete, the Connections list will be displayed.

- Activate the connection.

The screenshot displays a web interface with a navigation menu on the left and a main content area. The navigation menu includes 'IP Configuration', 'Telephony', 'Connections' (highlighted in orange), 'Audio', 'Number Assignment', 'Call Forwarding', 'Dialling Plans', 'Network Mailbox', 'Advanced Settings', 'Messaging', 'Services', 'Handsets', 'Security', and 'Miscellaneous'. The main content area is titled 'IP Connection' and contains a table with the following data:

	Name / Provider	Suffix	Status	Active
1.	My Account sippgate	#1	Registered	<input checked="" type="checkbox"/>
2.	IP2 sippgate	#2	Disabled	<input type="checkbox"/>
3.	IP3 Other Provider	#3	Disabled	<input type="checkbox"/>
4.	IP4 Other Provider	#4	Disabled	<input type="checkbox"/>
5.	IP5 Other Provider	#5	Disabled	<input type="checkbox"/>
6.	IP6 Other Provider	#6	Disabled	<input type="checkbox"/>

Below the IP Connection table, there is a section for 'Phonet.ch' with a table:

Name	Suffix	Status	Active
Phonet.ch	#9	Registered	<input checked="" type="checkbox"/>

At the bottom, there is a section for 'Fixed Line Connection' with a table:

Name	Suffix
Fixed Line	#0

You can then be reached on the corresponding VoIP phone number.