



Gigaset elements









Important notes on

Gigaset elements sensors and actuators

Safety precautions

Warning

Read the safety precautions and the enclosed leaflet "First Steps" before use.

| | |
|--|---|
|  | Use only the power adapter indicated on the devices. Use only the cable supplied for the LAN connection and connect it to the intended ports only. |
|  | Use only the following batteries: Lithium primary 3.0 Volt (Type CR123A or CR17345). Batteries, which are noticeably damaged, must be replaced. |
|  | Using your telephone may affect nearby medical equipment. Be aware of the technical conditions in your particular environment, e.g. doctor's surgery. If you use a medical device (e.g. a pacemaker), please contact the device manufacturer. They will be able to advise you regarding the susceptibility of the device to external sources of high frequency energy. |
|  | The devices are not splashproof. For this reason do not install them in a damp environment such as bathrooms or shower rooms. |
|  | Do not use the devices in environments with a potential explosion hazard (e.g. paint shops). |
|  | If you give your Gigaset elements base station, actuators and sensors to a third party, make sure you also give them the enclosed leaflet "First Steps". |
|  | Remove faulty devices from use or have them repaired by our Service team, as these could interfere with other wireless services |
|  | The volume of the acoustic alarm of the alarm siren may damage your hearing, if your ears are subjected to the tone for too long or too intensively. Therefore never put your ear close to the alarm siren! |



Batteries should not be disposed of in general household waste. Observe the local waste disposal regulations, details of which can be obtained from your local authority.

All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.

The crossed-out wheeled bin symbol on the product means the product is covered by the European Directive 2002/96/EC.

The correct disposal and separate collection of your old appliance will help prevent potential negative consequences for the environment and human health. It is a precondition for reuse and recycling of used electrical and electronic equipment.

For more detailed information about disposal of your old appliances, please contact your local council refuse centre or the original supplier of the product.

Important notes on installation and use

Use

Gigaset elements sensors and actuators are an extension of the Gigaset elements starter kit.

Requirements

To use the Gigaset elements sensors and actuators efficiently, the installed and fully functional Gigaset elements starter kit is required.

Installation

Gigaset elements sensors and actuators are designed for use in dry rooms in a temperature range of +5 °C to +45 °C.

The range is up to 300m in unobstructed outdoor areas and up to 50 m inside buildings.

Warning

Never expose the Gigaset sensors and actuators to the influence of heat sources, direct sunlight or other electrical devices and protect it from moisture, dust, corrosive liquids and fumes.

Gigaset elements door and window have to be glued with the sticky tapes provided.

Set up Gigaset elements motion either with the mounted pedestal or with the enclosed sticky tapes or install it on the wall with the enclosed screws and dowels. A description of where to ideally install the sensors and actuators can be found in the enclosed leaflet "First Steps".

Please contact the Gigaset elements customer service if you have any questions.

Notes on the sticky tapes

- ◆ Glue the sensors to clean, dry surfaces only which are also free of grease and if possible smooth and stable.
- ◆ Optimal bonding is achieved after approx. 48 hours.
- ◆ The sticky tapes are designed for use once only.
- ◆ Only use the sticky tapes provided.

Gigaset elements GmbH is not liable for potential damage to surfaces which may occur through glueing, mounting, assembling or removal of the Gigaset elements sensors and actuators.

Customer Service

Step by step to your solution with the Gigaset elements customer service.

Questions and answers

If you have questions during use, you can find proposals for solutions at www.gigaset-elements.com/en/FAQ

Contact our service personnel:

Couldn't find a solution under in the FAQs section?

We are happy to help ...

... by e-mail:

www.gigaset-elements.com/en/contact

Please have your receipt at the ready.

If the equipment is used in a manner inconsistent with this note, or with the instructions in the leaflet "First Steps" and on the product itself, this can influence the warranty claim (repair or replacement of the product).

In order to make use of the warranty, the product purchaser is asked to submit a receipt which proves the date of purchase (date from which the warranty period starts) and the type of goods that have been purchased.

Authorisation

These devices are intended for use within the European Economic Area and Switzerland. If used in other countries, they must first be approved nationally in the country in question.

We, Gigaset Communications GmbH, declare that these devices meet the essential requirements and other relevant regulations laid down in Directives 1999/5/EC and 2011/65/EU. For a copy of the Declaration of Conformity please contact the Gigaset customer service at:

www.gigaset-elements.com/en/contact



Care

Wipe the device with a **damp** cloth or an antistatic cloth. Do not use solvents or microfibre cloths.

Never use a dry cloth; this can cause static.

In rare cases, contact with chemical substances can cause changes to the device's exterior. Due to the wide variety of chemical products available on the market, it was not possible to test all substances.

Impairments in high-gloss finishes can be carefully removed using display polishes for mobile phones.

Contact with liquid

If one of the components comes into contact with liquid:

- 1 Disconnect the device from the power supply or remove the batteries.**
- 2 Allow the liquid to drain from the device.**
- 3 Pat all parts dry.**
- 4 Place the device in a dry, warm place for at least 72 hours**
(not in a microwave, oven etc.).
- 5 Do not switch on the device again until it is completely dry.**

When it has fully dried out, you will normally be able to use it again.

Open Source Software

General

Your Gigaset elements device includes, among other things, Open Source software that is subject to various licence conditions. The granting of rights of use with regard to the Open Source software that go beyond the operation of the unit in the form produced by Gigaset Communications GmbH is regulated in the relevant licence conditions of the Open Source Software. The corresponding licence conditions are printed at the end of this chapter in their original version.

Open Source Software: Door sensor, window sensor

Licence and copyright information

Your Gigaset elements device includes, among others, FreeRTOS, Version 7.0.1. The appropriate source code can also be requested from Gigaset Communications GmbH within three years of purchasing the product. Please use the contact details provided at www.gigaset-elements.com/en/contact.

Licence texts

Contiki:

Copyright (C) 1995, 1996, 1997, and 1998 WIDE Project.

Copyright (c) 2001-2003, Adam Dunkels.

Copyright (c) 2002-2003, Adam Dunkels.

Copyright (c) 2004, 2008, Swedish Institute of Computer Science.

Copyright (c) 2004, Adam Dunkels and the Swedish Institute of Computer Science.

Copyright (c) 2004, Swedish Institute of Computer Science.

Copyright (c) 2005, Swedish Institute of Computer Science.

Copyright (c) 2006, Swedish Institute of Computer Science.

Copyright (c) 2007, Swedish Institute of Computer Science.

Copyright (c) 2008, Swedish Institute of Computer Science.

Copyright (c) 2009, Swedish Institute of Computer Science.

Copyright (c) 2010, Swedish Institute of Computer Science.

Copyright (c) 2011, Swedish Institute of Computer Science.

Copyright (C) by RTX A/S, Denmark.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Newlib:

Copyright (c) 1990 Regents of the University of California.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:

This product includes software developed by the University of California, Berkeley and its contributors.

4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Open Source Software: Motion Sensor, Siren

Licence texts

Contiki:

Copyright (C) 1995, 1996, 1997, and 1998 WIDE Project.

Copyright (c) 2001-2003, Adam Dunkels.

Copyright (c) 2002-2003, Adam Dunkels.

Copyright (c) 2004, 2008, Swedish Institute of Computer Science.

Copyright (c) 2004, Adam Dunkels and the Swedish Institute of Computer Science.

Copyright (c) 2004, Swedish Institute of Computer Science.

Copyright (c) 2005, Swedish Institute of Computer Science.

Copyright (c) 2006, Swedish Institute of Computer Science.

Copyright (c) 2007, Swedish Institute of Computer Science.

Copyright (c) 2008, Swedish Institute of Computer Science.

Copyright (c) 2009, Swedish Institute of Computer Science.

Copyright (c) 2010, Swedish Institute of Computer Science.

Copyright (c) 2011, Swedish Institute of Computer Science.

Copyright (C) by RTX A/S, Denmark.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



Gigaset elements



A31008-N2511-F101-1-2X43

Issued by
Gigaset elements GmbH
Hansaallee 299, D-40549 Düsseldorf

© **Gigaset elements GmbH 2014**

Subject to availability.
All rights reserved. Rights of modifications reserved.
www.gigaset-elements.com

This user guide is made from 100% recycled paper.